

### LISTE DE RECAMBIOS / LIST OF SPARES

| Nº de parte<br>Part No. | Descripción<br>Description                             | E0032      |
|-------------------------|--|------------|
| 1                       | Carrocería<br>Bodyshell                                | ER0032/01  |
| 2                       | Set accesorios carrocería<br>Bodyshell accessories set | ER10100/02 |
| 3                       | Pistones<br>Pistons                                    | ER10100/03 |
| 4                       | Contrapeso<br>Weight                                   | ER10100/04 |
| 5                       | Circuito impreso<br>Printed circuit                    | ER10100/05 |
| 6                       | Engranaje con eje<br>Gear with axle                    | ER10100/06 |
| 7                       | Set motor<br>Motor set                                 | ER10100/07 |
| 8                       | Bloque bastidor<br>Main frame                          | ER10100/08 |
| 9                       | Set de bielas<br>Rods set                              | ER10100/09 |
| 10                      | Set de ruedas<br>Wheel set                             | ER0032/10  |
| 12                      | Base bastidor<br>Main frame base                       | ER10100/12 |
| 13                      | Enganche<br>Coupling                                   | ER058      |
| 14                      | Caja enganche x 2<br>Coupling box x 2                  | ER10100/14 |

